

Sash width (W)	Free width (w)
	$w = W - 100\text{mm}$
Sash height (H)	Free height (h)
620 - 719.9mm	$h = 500\text{mm}$
720 - 1000mm	$h = 600\text{mm}$

* Free height + free width = min. 1500mm